

MODEL 100XP ADDITIONAL INSTRUCTIONS

MM100XP_AdditionalInstructions(6X).doc

October 27, 2006

- 1. THE MODEL 100XP REQUIRES A SPECIAL METERS.INF FILE:** Replace the Meters.inf installed with the program (C:\PROGRAMF\MMV31\METERS.INF) with the one supplied on the enclosed diskette.
- 2. ALWAYS SET CORRECT PRESSURE ON DOWNLOAD:** As you finish downloading data, the "Customer Information" screen will display. Click "Change MM100 Settings" and select the correct pressure from the pull-down menu ("Model"). If you forget to select the pressure while downloading, you can change the pressure later in the Customer Information Screen when you create the graph or report. (This procedure is a work-around for a minor bug in the software to be fixed in the next version.)

NOTE: The Main Screen also has a pull-down menu that allows you to change the pressure in the unit itself. DO NOT use this pull-down to change the pressure setting.